

SV300

Einbau-Anleitung • Installation Instructions Instructions de montage • Istruzioni di montaggio

E1


Bauteile • Components • Pièces • Componenti

①= Pilotventil
Pilot valve
Vanne pilote
Valvola pilota

②= Filtereinsatz
Filter insert
Garniture de filtration
Inserto filtro



③= Absperr-Kugelhahn
Manual ball valve
Clapet à bille
Valvola di intercettazione a sfera

④= Nadelventil
Needle Valve
Soupape d'aiguille
Valvola a spillo




E2

Einbau • Installation • Installation • Installazione




E3

Inbetriebnahme • Commissioning • Mise en service Messa in servizio



P_B = Betriebsdruck
 P_B = Operating pressure
 P_B = Pression de service
 P_B = Pressione di esercizio

P_A = Ansprechdruck
 P_A = Opening pressure
 P_A = Pression de levée
 P_A = Pressione di apertura



Automation and Control Solutions

Honeywell GmbH
 Hardhofweg
 74821 MOSBACH
 GERMANY

Phone: (49) 6261 810
 Fax: (49) 6261 81309
 www.honeywell.com

Manufactured for and on behalf of the Environmental
 and Combustion Controls Division of Honeywell
 Technologies Sàrl, Ecublens, Route du Bois 37,
 Switzerland by its Authorised Representative
 Honeywell GmbH

MU1H-1336GE23 R0212
 Subject to change without notice
 © 2012 Honeywell GmbH

Honeywell